


Designer 1 USB Disk 114 designs.

Click on the Viking site and then click on Designer Updates on the right side of the screen and you will come to this screen.


http://www.husqvarnaviking.com/us/7118_8641.htm

Click where it says to Download the Classic Fashion, etc.




I have a special folder I created under the C drive where I download everything and I know right where it is. My “!Download” folder is in the “save in window” and I click on “save”.

I unzip the file by right clicking and extracting the files in the zipped file and this is what I see.



I insert my embroidery stick in the computer port and I highlight the unzipped files and drag them to the port holding the stick.




I can put the stick in the D1 USB sewing machine and it will read those files.

The original D1 or any other machine will NOT read those files. But, we can certainly save those files on our hard drive in VP3 format and then you can transfer the to a stick or a floppy using the Disk Manager program.


If you have 3D Embroidery, you do not have the correct Disk Manager in that program. That one reads floppies. But the Disk Manager USB that came on a separate disk with the D1 USB Machine or the converted D1 USB will read the designs.

The 4D Embroidery includes a new Disk Manager USB that will also read the designs.

So, what ever one you have, open the Disk Manager USB program (in 4D, it's under the "accessories").




This screen opens and when I click on “read the stick”, it reads the stick and any menus that hold designs or fonts will light up in Orange.



If you click on the first orange one, you will see the sample 100 designs on the screen.

If you click on the Disk 114, that’s the extra Fashion Collection designs. Click on that menu and then click on the “+” in front of it and you will notice that disk has two menus. The screen only shows 6 at a time so the rest are in Menu two.




Now that the designs are on the screen, we want to save them in vp3 format.

On the left side of the toolbar, you will see 4 floppies overlapping. That's the Multi save icon. Click on that icon. Click on that icon.



Notice that it will save these designs under the C drive and under 4D Embroidery and under My designs and the folder will be called Disk 114.

You can change that by clicking on the "browse button" and choosing a different location or create a new folder for them.



If you click on “make new folder” as it is now, the new folder would be under the “my documents” folder because that is what is highlighted.

If you click on the “+” in front of the “My computer”, then it will reveal the C drive. Then you can find where you want to create the new folder. Then click on OK and the designs will all be saved in vp3 format.

