

Hoop clips for Diamond hoops *By Janice Henning*

Take a good look at the clip and you will notice that the two wings should be upward.



Look at both ends of the clip. The part that goes over the outer hoop has a lip the width of the clip.



The front part of the clip has a smaller lip that fits between the double slots on the hoop and rest slides between the inner side of the hoop edge and the slots.

When you want to remove the hoops, turn the hoop over, release the hoop lever and push the inner hoop down. The clips should automatically fall loose.